

MagraHearth Decorative Brackets Instructions

Tools and materials needed:

(1) 9/16 Wrench	(4) 3/8" Bolts with (4) Rub Washer
(2) "L" Brackets	(2) Threaded Flat Face Plates

INSTALLATION INSTRUCTIONS

- Step 1: Place a "rub washer" on each 3/8 Bolt
- Step 2: Place "threaded flat face plate" behind "L" bracket. (As Seen in Picture 1 Below).
- Step 3: Insert 3/8" bolts with washers through the front of each "L" bracket and screw into threaded flat face plate. (Note: Hand tighten bolts for now to allow a little play when placing over mantel.)
- Step 4: Once you have assembled both brackets, place over mantel in desired spot, or over cut seam on a custom cut mantel. (Note: Use 9/16 wrench to tighten once in final position; as seen in Picture 2.)

Bracket Assembled (Picture 1)



Bracket Installed On Mantel (Picture 2)



Your installation of the MagraHearth Decorative Brackets should now be complete. If you have any questions, you can contact us at techsupport@magrahearth.com.