

# HIDDEN IN MY HEART

## ALBUM COLLECTION



## STREAM

[www.scripture-lullabies.com/stream](http://www.scripture-lullabies.com/stream)



SPOTIFY



APPLE MUSIC



AMAZON



PANDORA

## HOW TO CARE FOR YOUR TEDDY BEAR

- Spot clean only - wipe with a slightly damp cloth to keep clean. DO NOT submerge any part of your Teddy Bear or its charging unit in a sink, bathtub, lake, pool, washing machine ... you get the idea!
- Avoid damaging the battery by keeping your Teddy Bear away from direct heat or extreme cold.
- Periodically examine your Teddy Bear, battery charger, cables, and other parts for damage. If damaged, DO NOT use your Teddy Bear.
- Your Teddy Bear has a limited 6-month warranty. For more information, visit our website at [scripture-lullabies.com/bear-warranty](http://scripture-lullabies.com/bear-warranty).
- If you have any issues with your Teddy Bear, please do not contact the retailer from which it was purchased. Instead, email us directly at [info@scripture-lullabies.com](mailto:info@scripture-lullabies.com).

**WARNING:** This toy is for ages 3 and up. It contains small parts (choking hazard) and electronics. Your Teddy Bear should not be played at full volume close to a child's ear. In exceptional and very rare cases, the battery may leak fluids that could potentially cause a chemical burn, injury, or ruin the toy. To avoid battery leakage, DO NOT disassemble your Teddy Bear under any circumstance. Also, DO NOT operate your Teddy Bear if it is not working properly. Damage to electronics may result in fire, electric shock, or injury. DO NOT puncture the Teddy Bear or its battery, and DO NOT dispose of either in a fire. Should your Teddy Bear become unusable, dispose of this toy and its battery safely and according to local rules and regulations.



scripture lullabies®

## TEDDY BEAR




[WWW.SCRIPTURE-LULLABIES.COM](http://WWW.SCRIPTURE-LULLABIES.COM)

## IMPORTANT!

We know you will love your Scripture Lullabies musical Teddy Bear! As you listen to your Teddy Bear sing, may you absorb God's powerful truths and promises into your heart. Your Teddy Bear plays songs from our "Hidden In My Heart" album series, which are sure to bring peace wherever your Teddy Bear goes!

- Before playing with your Teddy Bear, read this manual carefully for important safety information, operating instructions, and warranty details.
- Charge fully for 3 hours before initial use.
- Inside your Teddy Bear is one non-replaceable, rechargeable, lithium-ion battery. Charging should ONLY be handled by an adult. The included USB charging unit (charging box and cable) is not a toy.
- Your Teddy Bear contains electronics and should only be used under adult supervision.



## PLAYTIME!

*Your Teddy Bear is very simple to operate:*

**SONGS (right foot):** Push to play and advance through 8 Scripture Lullabies songs.

**SOUNDS (left foot):** Push to play and advance through 4 calming sounds.

**VOLUME (left paw):** Push to cycle through 4 different volume levels.

**ON/OFF (right paw):** Push to turn your Teddy Bear on and off.

**TIMER:** Your Teddy Bear has an automatic timer that will shut off after 30 minutes.

**BATTERY:** Your Teddy Bear's battery provides 7-10 hours of play before needing to be recharged. To recharge, plug the USB cable (inside the zipper) into the charging unit or other USB power source. It will be fully charged in 3 hours.

**HEART LIGHT:** The heart illuminates only when the music plays, symbolizing God's Word hidden in your heart!



All songs written by Jay Stocker for BreakAway Music  
© 2009, 2011, 2013, 2021 Peace & Quiet Music, ASCAP



info@scripture-lullabies.com  
www.scripture-lullabies.com