





WATERFURNACE GEOTHERMAL FILTER GUIDE

STEP 1: LOCATE UNIT MODEL

Locate your unit's nameplate that contains the model number



Identify your unit's model and size to select the filter below



EXAMPLE
Model = NDV and
Size = 064

If your unit has a "1" before the D in the serial number, you have a special-order filter. Call ACES for more information.

STEP 2: IDENTIFY FILTER TYPE AND SIZE

Unit Type	Model	Unit Size	Filter Size	MERV Rating	Link 1 - Filtershipped.com	Link 2 - Filterbuy.com
WaterFurnace 7 Series	NVV	036	30x32x2	Merv 11	Filter Shipped 30x32x2	FilterBuy 30x32x2
WaterFurnace 7 Series	NVV	048	30x32x2	Merv 11	Filter Shipped 30x32x2	FilterBuy 30x32x2
WaterFurnace 7 Series	NVV	060	30x36x2	Merv 11	Filter Shipped 30x36x2	Filterbuy 30x36x2
WaterFurnace 5 Series	NDV	026	24x28x2	Merv 11	Filter Shipped 24x28x2	FilterBuy 24x28x2
WaterFurnace 5 Series	NDV	038	28x30x2	Merv 11	Filter Shipped 28x30x2	FilterBuy 28x30x2
WaterFurnace 5 Series	NDV	049	30x32x2	Merv 11	Filter Shipped 30x32x2	FilterBuy 30x32x2
WaterFurnace 5 Series	NDV	064	36x30x2	Merv 11	Filter Shipped 30x36x2	Filterbuy 30x36x2
WaterFurnace 5 Series	NDV	072	36x30x2	Merv 11	Filter Shipped 30x36x2	Filterbuy 30x36x2
WaterFurnace 3 Series	LDV	024	20x24x1	Merv 8	Filter Shipped 20x24x1	FilterBuy 20x24x1
WaterFurnace 3 Series	LDV	036	24x24x1	Merv 8	FilterShipped 24x24x1	FilterBuy 24x24x1
WaterFurnace 3 Series	LDV	048	28x30x1	Merv 8	Filter Shipped 28x30x1	FilterBuy 28x30x1
WaterFurnace 3 Series	LDV	060	28x30x1	Merv 8	Filter Shipped 28x30x1	FilterBuy 28x30x1
WaterFurnace 3 Series	LDV	072	30x32x1	Merv 8	Filter Shipped 30x32x1	FilterBuy 30x32x1

View NVH, NDH and LDH Models on the Next Page

STEP 2: IDENTIFY FILTER TYPE AND SIZE

Unit Type	Model	Unit Size	Filter Size	MERV Rating	Links to Purchase
WaterFurnace 7 Series*	NVH	036	20x20x2 and 20x22x2	Merv 11	20x20x2 and 20x22x2
WaterFurnace 7 Series*	NVH	048	20x20x2 and 20x22x2	Merv 11	20x20x2 and 20x22x2
WaterFurnace 7 Series*	NVH	060	20x25x2 and 20x22x2	Merv 11	20x20x2 and 20x22x2
WaterFurnace 5 Series	NDH	026	18x32x2	Merv 11	18x32x2
WaterFurnace 5 Series	NDH	038	20x37x2	Merv 11	20x37x2
WaterFurnace 5 Series*	NDH	049	20x20x2 and 20x22x2	Merv 11	20x20x2 and 20x22x2
WaterFurnace 5 Series*	NDH	064	20x25x2 and 20x22x2	Merv 11	20x25x2 and 20x22x2
WaterFurnace 5 Series*	NDH	072	20x25x2 and 20x22x2	Merv 11	20x25x2 and 20x22x2
WaterFurnace 3 Series	LDH	024	18x24x1	Merv 8	18x24x1
WaterFurnace 3 Series	LDH	036	18x32x1	Merv 8	18x32x1
WaterFurnace 3 Series	LDH	048	20x37x1	Merv 8	20x37x1
WaterFurnace 3 Series	LDH	060	20x37x1	Merv 8	20x37x1
WaterFurnace 3 Series*	LDH	072	20x20x1 and 20x22x1	Merv 8	20x20x1 and 20x22x1

*Unit requires (2) filters of different sizes

If you have any questions about your filter size before you order, give us a call in the office at (585)935-7186



STEP 3: TURN OFF UNIT & INSERT FILTER

Ensure geothermal unit is **turned off** before proceeding!
You can turn off the unit at the thermostat (**MODE > OFF**).



Remove filter housing door



Remove Old Filter



Insert New Filter
Ensure proper airflow
Each filter should have a directional arrow

Questions?
Give us a call in the
office at (585)935-7186